

## Operating Instructions

### flowtherm NT

Software status from 2.01



**Multifunctional handheld unit with data logger for measuring flow rate, flow velocity, temperature, pressure and other variables**

## Overview and brief introduction of controls and connections



Please ensure that the correct sensor (FA, VA or TA) is selected (see under 5.3.20.1)!

## Contents

1	Safety Instructions.....	4
1.1	Specific information.....	4
1.2	Handling batteries and accumulators .....	5
2	Scope of Delivery.....	5
2.1	Description, type plate.....	5
3	Technical Specifications .....	7
3.1	Operating conditions.....	7
3.2	Housing and connection .....	7
3.3	Electrical data.....	7
3.4	Measurement uncertainty.....	8
4	Initial Operation / Startup.....	8
4.1	Connector sockets.....	8
4.2	Wiring diagram for the 8-pin connector plug.....	9
4.3	Wiring diagrams for the 12-pin connector plug.....	10
5	Operation .....	11
5.1	Key functions.....	11
5.2	Setup menu after switch on: .....	13
5.3	Parameter settings.....	15
5.3.1	FA - Basic settings .....	15
5.3.2	FA - Measurement settings.....	16
5.3.3	FA - Density correction .....	17
5.3.4	FA - Operating conditions .....	18
5.3.5	FA - Standard conditions .....	18
5.3.6	FA - Pairs of values .....	18
5.3.7	VA - Basic settings .....	19
5.3.8	VA - Measurement settings .....	19
5.3.9	VA - Operating conditions.....	20
5.3.10	VA - Standard conditions .....	20
5.3.11	VA - Pairs of values .....	21
5.3.12	TA - Basic settings .....	21
5.3.13	TA - Measurement settings.....	21
5.3.14	TA - Standard conditions .....	22
5.3.15	TA - Pairs of values .....	23
5.3.16	Pt100 - Unit .....	23
5.3.17	Analog input.....	23
5.3.18	Output.....	24
5.3.19	Counter .....	24
5.3.20	Display .....	24
5.3.21	Long-term measurement .....	26
5.3.22	Device .....	28
5.3.23	Factory settings.....	28
5.3.24	Data logger.....	28
5.3.25	Device status.....	29
5.3.26	Device profiles.....	30
5.3.27	Key F3 - LM-Start .....	30
5.3.28	Key 4 Switch off / OFF (reset) .....	30
6	Troubleshooting.....	31
7	Replacement Parts .....	32
8	Installation.....	32
9	Maintenance.....	32



## 1 Safety Instructions

Danger to life, risk of injury and damage to material or property.  
Read the Operating Instructions carefully before initial operation.  
Observe general safety precautions as well as those included in various sections of these Operating Instructions.

Hazard risks:

- non-observance of the Operating and Safety Instructions
- modifications to the device by the customer
- handling the device outside the specified operating conditions
- handling the sensors outside the specified operating conditions
- use of unsuitable power supplies and peripheral devices
- improper use of the device

Prevention of voltage hazards:

- use only the dedicated adapter plug for the mains supply
- make sure that the PC is correctly connected to the mains (earthed safety socket, earthing) when using a USB connection
- when connecting analog outputs or inputs to peripheral devices make sure that these are correctly connected to the mains (earthed safety socket, earthing)

Danger when installing the sensors in pressurized pipelines:

- sensors for use in pressurized pipelines are to be inserted or retracted only in depressurized conditions; non-observance may result in serious injuries to personnel
- when installing or removing under pressure, the appropriate protective equipment must be used, e.g. ball valve and probe guide pieces with chain guard or spindle probe guide pieces



### 1.1 Specific information

- pay special attention to the mains voltage when using voltage converters
- observe the maximum power rating when connecting sensors powered by more than 12 V
- when operating out of doors make sure that the battery compartment cover and sensor plug are screwed on tightly, the connector sockets not in use are firmly capped, and the USB connection cover is tightly sealed, otherwise the IP65 protection cannot be guaranteed



## 1.2 Handling batteries and accumulators

- All batteries/accumulators must be replaced at the same time. Do not replace single cells! All replacements must be identical (cell type / nominal capacity / make) and fitted the right way round. Possible reverse polarity of single cells is to be avoided (electrolyte formation)
- Recharge batteries with a suitable charger away from the unit
- Remove batteries when they are dead or if the device is not being used for any length of time to avoid leakage
- Batteries contain hazardous substances and must never be disposed of in household waste
- Never recharge normal batteries

## 2 Scope of Delivery

- handheld flowtherm NT
- Operating Instructions and Data Sheet flowtherm NT
- FA, VA or TA sensor(s) as ordered
- relevant Data Sheet for above
- other sensors such as Pt100, if ordered
- accessories for sensors, e.g. extension rod for FA sensor, if ordered - CD-ROM with PC software HLOG II and USB cable (optional)
- adapter plug and USB cable (optional)
- various connection and extension cables, connectors (optional)
- carrying case (optional)


Please check that everything listed in the Delivery Note / Technical Data Sheet is included in the delivery.

### 2.1 Description, type plate

The flowtherm NT is a multifunctional handheld unit with data logger for measuring flow velocity, volume flow/flow rate, standard flow rate, mass flow rate, temperature, pressure and other variables, insofar as they are measurable / deducible with connectable sensors:

- vane wheel FA, FAR, FT, FADi, FARDi
- vortex VA, VAT, VADi
- thermal TA10, TADi
- temperature Pt100
- 2-wire 4-20 mA 12 V supply
- 3- or 4-wire 4-20 mA output and 12 V supply
- 3- or 4-wire 0-10 V output and 12 V supply

The following type plate is found on the back of the unit:



Description of type plate specifications:

- 1: Description  
see Section 2.1
- 2: Unit and serial no.
- 3: Year of production
- 4: Inputs  
see Description Section 2.1  
see Connector sockets Section 4.1  
see Wiring diagrams Section 4.2 and 4.3
- 5: Outputs  
see Electrical data Section 3.3  
see Connector sockets Section 4.1  
see Wiring diagrams Section 4.3
- 6: USB connection  
see Electrical data Section 3.3  
see Connector sockets Section 4.1
- 7: Power supply  
see Safety Instructions Section 1  
see Electrical data Section 3.3
- 8: Operating conditions  
see Safety Instructions Section 1  
see Operating conditions Section 3.1

### 3 Technical Specifications



#### 3.1 Operating conditions

Ambient temperature  
of connection housing in service : -20 ... +50 °C

Type of protection : IP65

#### 3.2 Housing and connection

Type of protection : IP65 with battery compartment cover and sensor plug screwed on tightly, connector sockets not in use firmly capped, and USB connection cover tightly sealed

Material : electrically conductive ABS plastic

External measurements, weight : W/H/L = 96/42/197 mm, approx. 520 g

Connections : 5-pin connector plug for thermal sensors

: 8-pin connector plug for vane wheel, vortex or temperature sensors

: 12-pin connector plug for analog outputs or inputs

USB for data logger readout, configuration and external power supply via PC or mains adapter

#### 3.3 Electrical data

**Power supply** : via 4 alkaline manganese (LR6) Mignon (AA) 1.5V batteries  
(maximum permissible nominal capacity 4000 mAh per cell)  
running time (Duracell Plus) approx. 24 hours  
(using FA sensor without display light)  
or via 4 NiMH rechargeable Mignon (AA) 1.2V batteries  
running time (Ansmann Digital 2850 mAh) approx. 26 hours  
(using FA sensor without display light)



Open the battery compartment with a screw driver. Always change all 4 batteries at the same time, checking for correct polarity. Only ever recharge batteries away from the unit using a suitable charger. Always ensure that all 4 rechargeable batteries are fully charged before inserting. To close the compartment press it firmly in the seal (in the direction of the connector sockets) and screw down tightly.

**Mains supply** : via USB connection with PC or adapter plug

**Supply current** : via USB connection not less than 300 mA



The mains supply is not electrically isolated from the outputs. The "-" connection of the analog outputs and the earth of the USB connection have the same potential, i.e. for EMC reasons a peripheral device should have potential-free inputs for evaluation of the analog outputs when connecting to a PC.

<b>Analog outputs (2 x)</b>	: 0 ... 10 V with internal resistance of 1000 Ohm; measured, initial and final values adjustable as appropriate
<b>Analog input 4-20 mA</b>	: for connection of sensor in 2-wire system with $\leq 12$ V; allocation of unit, initial value and final value adjustable
<b>Analog input 0-10 V</b>	: for connection of sensors with voltage output; input resistance 5 MOhm; $\leq 12$ V power supply for sensors, max. 100 mA; allocation of unit, initial value and final value adjustable

### 3.4 Measurement uncertainty

<b>Input FA</b>	: +/- 1 Hz
<b>Input VA</b>	: +/- 1 Hz
<b>Input TA</b>	: +/- 1 (0.7 % of measured value + 0.02 % FS)
Temperature display	: +/- 1 Kelvin
<b>Analog input 0-10 V</b>	: +/- 1 (0.3 % of measured value + 0.02 % FS)
<b>Analog input 4-20 mA</b>	: +/- 1 (0.3 % of measured value + 0.02 % FS)
<b>Input Pt100</b>	: +/- 0.2 Kelvin
<b>Analog output 1+2, 0-10 V</b>	: +/- 1 (0.2 % of measured value + 0.02 % FS)

All values apply for a set damping rate of 30 seconds during measurement. In addition, the measurement uncertainty of the utilised sensors must be taken into consideration.



## 4 Initial Operation / Startup

For installation and operation of the system the national regulations currently in force, the recognised standards of good practice and these Operating Instructions apply.

### 4.1 Connector sockets



5-pin connector socket:  
for thermal sensors TA10 and TADi measuring tubes



8-pin connector socket:  
for vane wheel sensors FA, FAR, FT and FADi measuring tubes  
for vortex sensors VA, VAT and VADi measuring tubes  
for temperature sensors Pt100



Always connect just one sensor at a time!



12-pin connector socket:  
 for analog outputs 2 x 0-10 V  
 for analog input 4-20 mA  
 for analog input 0-10 V



USB connector socket type B  
 data logger readout, hardware configuration  
 for external power supply via PC or adapter plug



Always make sure that the connector sockets not in use are firmly capped, the sensor plug is screwed on tightly and the USB connection cover is tightly sealed, otherwise the IP65 protection cannot be guaranteed



## 4.2 Wiring diagram for the 8-pin connector plug

Electrical connection must be carried out according to the relevant wiring diagram.  
**Incorrect connection can cause serious damage to the electronics.**

Wiring diagram with view of solder contacts:

### Pin assignment

Pin 1: v/FA+FAR signal 1  $\square$  or v/VA signal  $\square$

Pin 2: ground  $\perp$

Pin 3: Pt100

Pin 4: Pt100



Pin 5: Pt100

Pin 6: Pt100

Pin 7: v/FAR signal 2  $\square$

Pin 8: V+

Housing: shield





## 4.3 Wiring diagrams for the 12-pin connector plug


Electrical connection must be carried out according to the relevant wiring diagram.  
**Incorrect connection can cause serious damage to the electronics.**

Wiring diagrams with view of solder contacts:

### 4.3.1 Analog outputs 0-10 V

C = analog output port 1  
 D = analog output port 2  
 E = signal - (0 V)


plug shell = shielding



### 4.3.2 Analog input 4-20 mA (2-wire system current for 12V supply)

A = power supply + (12V)  
 F = power supply -

plug shell = shielding




### 4.3.3 Analog input 4-20 mA (3 or 4-wire system current for 12V supply)

A = power supply + (12V)  
 B = power supply - (0V)  
 F = signal +

H = signal - (0V)

plug shell = shielding




### 4.3.4 Analog input 0-10 V (3 or 4-wire system voltage for 12V)

A = power supply + (12V)  
 B = power supply - (0V)  
 G = signal +

H = signal - (0V)

plug shell = shielding



## 5 Operation

### 5.1 Key functions

**Switch on:** with the  key (also )  
hold down until text appears in the display.

**Switch off:** with the  key (also )  
press briefly and wait until the display goes off.

 **Reset!** Should the unit no longer react to key operation, switch off can be enforced by holding down the off key for more than 10 seconds.

**Control keys:** ,  and  are keys with variable function, identified in the bottom row of the display depending on user level.

**Arrow keys:** **In measured value display / view after switch on:**  
during measured value display the arrow keys have the following function:  
 and  : shift the display. Definition whether the values from 1, 2 or 3 input channels are displayed simultaneously. Depending on selection, the character size of the display value changes.  
 and  : is the display so set that only measured values from 1 or 2 input channels are displayed simultaneously, then these keys can be used for scrolling through the input channels.

**In the menus and input boxes:**  
, ,  and  are control keys for navigating within the various menus and menu levels.

**ok key:** **In the measured value display / view after switch on:**  
 is a control key for switching the display light on or off.

**In the menus and input boxes:**  
 is a control key to select and save.

## Examples for key functions in the menus:

### Menu selection list:

With   up or down in the list; the selected element is highlighted.


With  a menu level higher (backwards).

With  a menu level lower (forwards) = select.

With  select = a menu level lower (forwards).

With  return to measured value display.

With  switch off.



### Parameter value selection window:


With   new selection element; the selected element flashes (here "mn").

With  select and save and return to selection list.

With  return to measured value display without saving.

With  return to selection list without saving.

With  switch off.



### Parameter value digit (numeric/text) setting:

With   change digit; the selected and editable digit flashes (here "1").


With   1 digit to the left or right respectively.

With  select and save and return to selection list.


With  return to measured value display without saving.


With  return to selection list without saving.

With  switch off.



## 5.2 Setup menu after switch on:





LM-Start **f2**  
5.3.27

Logger **f3**

- Switching on / off 5.3.24.1
- View 5.3.24.2
- Settings 5.3.24.3
- Delete 5.3.24.4

Off/ Reset **f4**  
5.3.28

## 5.3 Parameter settings

### Settings for vane wheel sensors FA:

#### 5.3.1 FA - Basic settings

*Menu -> Settings -> Sensor -> FA input -> Basic settings*

The connected **vane wheel sensor** determines the parameter type, measuring range, material and directional sensing to be set.

##### 5.3.1.1 Type

Setting the vane wheel type:

This can be determined from the serial no. on the sensor.

Selection:	<b>mc</b>	=	<b>micro</b> - for use in for instance: cylinder probes with OD 14, 16, 18 mm measuring tubes with ID 9.7 mm
	<b>mn</b>	=	<b>mini</b> for use in for instance: cylinder probes with OD 25 mm measuring tubes with ID 18.2 mm
	<b>md</b>	=	<b>midi</b> for use in for instance: cylinder probes with OD 30 mm
	<b>pairs of values</b>	=	special calibration characteristic specifically matched to the measuring task based on up to 30 supporting points. Input or changing the points, see under 5.3.6

Distinctive feature of sensors with vane wheel types **md3** and **ms** (measuring tube):

These sensors are always supplied with a special calibration characteristic. Therefore, always select **pairs of values**. For input or change see (5.3.6) pairs of values.

##### 5.3.1.2 Range

Setting the vane wheel measuring range:

This can be determined from the serial no. on the sensor.

Selection:	<b>20</b>	=	measuring range up to <b>20 m/s</b>
	<b>40</b>	=	measuring range up to <b>40 m/s</b>
	<b>80</b>	=	measuring range up to <b>80 m/s</b>
	<b>120</b>	=	measuring range up to <b>120 m/s</b>



Exceeding the measuring range can cause permanent damage to the vane wheel!

##### 5.3.1.3 Material

Setting the vane wheel sensor material:

This can be determined from the serial no. on the sensor.

Selection:	<b>steel</b>	=	<b>E</b>
	<b>aluminium</b>	=	<b>A</b>
	<b>titanium</b>	=	<b>T</b>

##### 5.3.1.4 Directional sensing

Setting the directional sensing function: such sensors are identified by an "R" in the serial number.

Selection:	<b>Y</b>	=	directional sensing <b>yes</b> , measured value display <b>with prefix</b>
	<b>N</b>	=	directional sensing <b>no</b> , measured value display <b>without prefix</b>





If the working medium density is not known, it can be determined with the formula:

$$W\text{-density} = P / (R * T)$$

where P = absolute pressure in Pa, R = specified gas constant in J/(kg\*K), T = temperature in K.

Here the specified gas constants of some gases:

sample gas	specific gas constant in J/(kg*K)	sample gas	specific gas constant in J/(kg*K)
dry air	287	hydrogen H <sub>2</sub>	4124
steam H <sub>2</sub> O	462	methane CH <sub>4</sub>	518
argon Ar	208	nitrogen N <sub>2</sub>	297
carbon dioxide CO <sub>2</sub>	189	oxygen O <sub>2</sub>	260
carbon monoxide CO	297	propane C <sub>3</sub> H <sub>8</sub>	189
helium He	2077	sulphur dioxide SO <sub>2</sub>	130

### 5.3.4 FA – Operating conditions

*Menu -> Settings -> Sensor -> FA input -> Operating conditoinis*

When choosing the relevant units (see 5.3.20.6) service temperature and working pressure are needed for calculation purposes. The operating conditions can be entered in this menu or determined with connected sensor.

#### 5.3.4.1 Service temperature

Measured or entered unit in °C

#### 5.3.4.2 Working pressure

Measured or entered unit in hPa

### 5.3.5 FA – Standard conditions

*Menu -> Settings -> Sensor -> FA input -> Standard conditions*

Standard conditions for Höntzsch are +21 °C (70 °F) and 1014 hPa (14.7 psia). Any standard can be set via the standard temperature and standard pressure parameters.

#### 5.3.5.1 Standard temperature

Input value in °C

#### 5.3.5.2 Standard pressure

Input value in hPa

#### 5.3.5.3 Standard density

Input value in kg/m<sup>3</sup> depending on set standard conditions for calculating the mass flow rate.

### 5.3.6 FA - Pairs of values

*Menu -> Settings -> Sensor -> FA Input -> Pairs of values*

If pairs of values is selected (see 5.3.1.1), then the values stored here for determining the measured value are applied as a calibration curve.

Selection:     **Configuration**           = enter the **quantity** of pairs of values (minimum 2, maximum 30) for processing and display

**Pairs of values**       = display and amend pairs of values.  
   A pair of values always consists of a velocity value in m/s and a frequency value in Hz.  
   The condition being: the pairs of values must be ever increasing, i.e. the next velocity and frequency value must always be greater than the previous one.

Example for quantity = 03  
01:000.50m/s, 00010Hz  
02:010.00m/s, 00350Hz  
03:040.00m/s, 01770Hz



If the frequency measured value is greater than in the last pair of values, then the velocity value is calculated. However, this means that the measurement uncertainty increases as this value is then outside the calibrated range. The measuring range in the serial no. and technical data sheet must not be exceeded, as this may cause permanent damage to the vane wheel! (For further information refer to 5.3.1).

## Settings for vortex sensors VA:

### 5.3.7 VA - Basic settings

*Menu -> Settings -> Sensor -> VA Input -> Basic settings*

The connected **vortex sensor** determines the parameter type.

#### 5.3.7.1 Type

Setting the type:

Refer to the relevant technical documents for selection options.

Selection:    **KKZ**               = the **calibration number (KKZ)** is individually determined for each sensor and modifies the basic characteristics.  
  **KKZ:** enter as an 8-digit figure, in which each digit has a 0..9..A..F range (hexadecimal = 16 possible variables).  
  The actual KKZ can be found in the technical data sheet, calibration certificate or directly on the sensor

**pairs of values** = special calibration characteristic specifically matched to the measuring task based on up to 30 supporting points. Entering or amending the points, see under 5.3.11.  
  The actual pairs of values are documented in the technical documents.

### 5.3.8 VA - Measurement settings

*Menu -> Settings -> Sensor -> VA Input -> Measurement settings*

The measuring task to be carried out determines the parameter, section and profile factor to be set.

#### 5.3.8.1 Section

Setting the measuring section for measuring in pipelines for flow rate display:

Selection:    **Circular**       = for pipes with circular section  
  **di/mm:** enter the ID in mm

**Rectangular** = for pipes with rectangular section  
  **a/mm:** enter the inner surface a in mm  
  **b/mm:** enter the inner surface b in mm

#### 5.3.8.2 Profile factor

The profile factor PF specifies the ratio of mean flow velocity in the measuring section and the flow velocity measured from the sensor. Requirements are: centric sensor positioning, non-rotational inlet flow and adequately dimensioned input/output sections. (See also Documents U155 and U206).

Following profile factors are to be set for vortex sensors VA40 subject to the pipe diameter:

Pipe ID in mm	PF for VA40	Pipe ID in mm	PF for VA40
80	0.719	160	0.808
90	0.729	170	0.819
100	0.738	180	0.830
110	0.750	190	0.839
120	0.761	200	0.842
130	0.773	300	0.845
140	0.784	400	0.850
150	0.796	...	0.850

For measurements in larger free jet as well as larger ducts or measuring tubes PF = 1.000 results in the local/punctual velocity.

With **f3** TABLE a profile factor subject to the set diameter of the measuring surface (5.3.8.1) is recommended. This value can be verified or also amended before saving. With rectangular selected as measuring surface, the surface is converted to circular for the proposed value and this value is approximate.



PF = 1.000 must always be set for VADi... measuring tubes calibrated with pairs of values!

### 5.3.8.3 Damping

The damping rate set here affects the measured value display, if VA is selected as sensor in the display settings (5.3.20.1). Damping also affects the analog output, if VA is selected as the source (see 5.3.18).

**Damping/s:** enter the damping time from 01 to 99 seconds

Example 10 seconds: after every second the arithmetical average from the last 10 seconds is displayed.

### 5.3.9 VA – Operating conditions

*Menu -> Settings -> Sensor -> VA Input -> Operating conditions*

When selecting the relevant units (see 5.3.20.6) service temperature and working pressure are needed for calculation purposes. The operating conditions can be entered in this menu, or determined with connected sensor.

#### 5.3.9.1 Service temperature

Measured or entered value in °C

#### 5.3.9.2 Working pressure

Measured or entered value in hPa

### 5.3.10 VA – Standard conditions

*Menu -> Settings -> Sensor -> VA Input -> Standard conditions*

Standard conditions for Höntzsch are +21 °C (70 °F) and 1014 hPa (14.7 psia). Any standard can be set via the standard temperature and standard atmospheric pressure parameters.

#### 5.3.10.1 Standard temperature

Input value in °C

#### 5.3.10.2 Standard atmospheric pressure

Input value in hPa

#### 5.3.10.3 Standard density

Input value in kg/m<sup>3</sup> depending on set standard conditions for calculating the mass flow rate.

### 5.3.11 VA - Pairs of values

*Menu -> Settings -> Sensor -> VA Input -> Pairs of values*

If pairs of values is selected (see 5.3.7.1), then the values stored here for determining the measured value are applied as a calibration curve.

- Selection:     **Configuration**         = enter the **quantity** of pairs of values (minimal 2, maximal 30) for processing and display
- Pairs of values**         = display and change of pairs of values.  
   A pair of values always consists of a velocity value in m/s and a frequency value in Hz.  
   The condition being: the pairs of values must be ever increasing, i.e. the next velocity and frequency value must always be greater than the previous one.

Example for quantity = 03  
 01:000.50m/s, 00010Hz  
 02:010.00m/s, 00350Hz  
 03:040.00m/s, 01770Hz



If the frequency measured value is greater than in the last pair of values, then the velocity value is calculated. However, this means that the measurement uncertainty increases as this value is then outside the calibrated range.

## Settings for thermal sensors TA:

### 5.3.12 TA - Basic settings

*Menu -> Settings -> Sensor -> TA Input -> Basic settings*

The connected **thermal sensor** determines the parameter type.

#### 5.3.12.1 Type

Setting the type of thermal sensor:

Refer to the relevant technical documents for selection options.

- Selection:     **KKZ**                     = the **calibration number (KKZ)** is individually determined for each sensor and modifies the basic characteristics.  
   **KKZ:** enter as a 14-digit figure, in which each digit has a 0..9..A..F range (hexadecimal = 16 possible variables).  
   The actual KKZ can be found in the technical data sheet, calibration certificate or directly on the sensor
- pairs of values** = special calibration characteristic specifically matched to the measuring task based on up to 30 supporting points. Entering or amending the points, see under 5.3.15  
   The actual pairs of values can be found in the technical documents.

### 5.3.13 TA - Measurement settings

*Menu -> Settings -> Sensor -> TA Input -> Measurement settings*

The task to be carried out determines the parameter, section and profile factor to be set.

#### 5.3.13.1 Section

Setting the measuring section for measuring in pipelines for flow rate display:

- Selection:     **Circular**                 = for pipes with circular section  
   **di/mm:** enter the ID in mm
- Rectangular**         = for pipes with rectangular section  
   **a/mm:** enter the inner surface a in mm  
   **b/mm:** enter the inner surface b in mm

### 5.3.13.2 Profile factor

The profile factor PF specifies the ratio of mean flow velocity in the measuring section and the flow velocity measured from the sensor. Requirements are: centric sensor positioning, non-rotational inlet flow and adequate dimensioned input/output sections. (See also Documents U232 and U234).

Following profile factors are to be set for thermal flow sensors TA10 subject to the pipe diameter:

Pipe ID in mm	PF for thermal sensors TA10
25	0.725
27.2	0.740
35.9	0.790
40	0.810
41.8	0.820
50	0.840
...	0.840

For measuring in larger free jet as well as larger ducts or measuring tubes with setting PF = 1.000 the local/punctual velocity will be displayed.

with  TABLE a profile factor subject to the set diameter of the measuring surface (5.3.13.1) is recommended. This value can be verified or also amended before saving. With rectangular selected as measuring surface, the surface is converted to circular for the proposed value and this value is approximate.



PF = 1.000 must always be set for TADi.. measuring tubes calibrated with pairs of values!

### 5.3.13.3 Pressure

Working pressure in hPa as absolute pressure for zero correction.

### 5.3.13.4 Damping

The damping rate set here affects the measured value display, if TA is selected as sensor in the display settings (5.3.20.1). Damping affects the analog output, if TA is selected as the source (see 5.3.18).

**Damping/s:** enter the damping time of 01 to 99 seconds

Example 10 seconds: after every second the arithmetical average of the last 10 seconds is displayed.

## 5.3.14 TA – Standard conditions

*Menu -> Settings -> Sensor -> TA Input -> Standard conditions*

Standard conditions for Höntzsch are +21 °C (70 °F) and 1014 hPa (14.7 psia). Any standard condition can be set via the standard temperature and standard atmospheric pressure parameters.

### 5.3.14.1 Standard temperature

Input value in °C

### 5.3.14.2 Standard pressure

Input value in hPa

### 5.3.14.3 Standard density

Input value in kg/m<sup>3</sup> depending on set standard conditions for calculating the mass flow rate.

### 5.3.15 TA - Pairs of values

*Menu -> Settings -> Sensor -> TA Input -> Pairs of values*

If pairs of values is selected (see 5.3.12.1), then the values stored here for determining the measured value are applied as a calibration curve.

- Selection:     **Configuration**         = enter the **quantity** of pairs of values (minimal 2, maximal 30) for processing and display
- Pairs of values**         = display and change of the pairs of values.  
   A pair of values always consists of a velocity value in m/s and a frequency value in Hz.  
   The condition being: the pairs of values must be ever increasing, i.e. the next velocity and frequency value must always be greater than the previous one.

Example for quantity = 03  
 01:000.50m/s, 06000Hz  
 02:010.00m/s, 08350Hz  
 03:040.00m/s, 12770Hz



If the frequency measured value is greater than in the last pair of values, then the velocity value is calculated. However, this means that the measurement uncertainty increases as this value is then outside the calibrated range.

**Note:** For switching between different calibration gases each pair of values calibration for the respective calibration gas can be saved in its own profile (see 5.3.26)



Resetting the factory settings (see 5.3.23) has no impact on the saved profile. Changing the pairs of values for the various calibration gases can only be reconstructed via the documentation in the Technical Data Sheet and calibration certificate.

## Pt100 input settings for temperature measurement :

### 5.3.16 Pt100 - Unit

*Menu -> Settings -> Sensor -> Pt100 Input -> Unit*

The parameter unit to be set here affects the measured value display

- Selection:     °C         = display of **temperature** in °C  
                   °F         = display of **temperature** in °F

## Analog input settings:

### 5.3.17 Analog input

*Menu -> Settings -> Sensor -> Analog input*

- Input:**         Selection:     **4-20mA** = **current input** 4-20 mA is selected  
   **0-10V**   = **voltage input** 0-10 V is selected

**Designation:**         for each of the two inputs a designation of up to 13 digits for the sensor can be entered.  
   Example: pressure sensor

**Equivalency:** for each of the two inputs a display equivalency can be defined. For this purpose the desired initial value of 4 mA or 0 V and the desired final value of 20 mA or 10 V is entered respectively.  
Example: 4 ... 20 mA -> 900 ... 1600 hPa

**Unit:** for each of the two inputs a unit of up to 5 digits for measured value display can be entered.  
Example: hPa  
(unused digits are marked with an "\*" and are not shown in the display and data logger)

## Analog output settings:

### 5.3.18 Output

*Menu -> Settings -> Output*

Settings for both analog output ports 1 and 2

#### 5.3.18.1 Port

Selection of **analog output port** 1 or 2. Setting the selected port under (5.3.18.2)

#### 5.3.18.2 Source

Setting the source and measuring value equivalency for the **analog output port** selected under 5.3.18.1.

Selection: **FA, VA, TA** = **flow sensor** depending on selection under (5.3.20.1)  
**equivalency:** initial value analog output at 0 V in m/s  
final value analog output at 10 V in m/s  
example: 0 ... 10 V -> 0 ... 40 m/s  
or: 0 ... 10 V -> 5 ... 20 m/s

**Pt100** = **temperature sensor Pt100**  
**Equivalency:** initial value analog output at 0 V in °C  
final value analog output at 10 V in °C  
example: 0 ... 10 V -> -20 ... +100 °C

## Counter settings:

### 5.3.19 Counter

*Menu -> Settings -> Counter*

#### 5.3.19.1 Reset

Resets counter to 0

#### 5.3.19.2 Decimals

Determines the number of decimal places (0, 1 or 2) for display

## Display settings:

### 5.3.20 Display

*Menu -> Settings -> Display*

Settings for measured value display. Determines the quantity of the simultaneously displayed values / input channel and assignment of these values to the 3 channels.

#### 5.3.20.1 Sensor

Selection: **Sensor:** = flow sensor selection

**FA:** = vane wheel sensor

**VA:** = vortex sensor

**TA:** = thermal sensor

Only the selected sensor may be connected!

### 5.3.20.2 Rows

The number of rows determines in how many input channels (1, 2 or 3) the measured values are displayed simultaneously after switch on.

### 5.3.20.3 Row 1

Selection of which measured value is allocated to input channel 1 and displayed as Row 1.

Selection:	<b>Date</b>	=	<b>actual date</b>
	<b>Time</b>	=	<b>actual time</b>
	<b>Unit</b>	=	unit of selected <b>flow sensor</b> (see 5.3.20.6 and 5.3.20.7)
	<b>Pt100 input</b>	=	<b>temperature sensor Pt100</b>
	<b>20mA input</b>	=	<b>analog input 4-20 mA</b>
	<b>10V input</b>	=	<b>analog input 0-10 V</b>
	<b>TAT input</b>	=	<b>temperature measurement of thermal sensor TA</b> (only relevant if a TA sensor is selected under 5.3.20.1)
	<b>Counter</b>	=	<b>counter</b> (see 5.3.19)

### 5.3.20.4 Row 2

Selection of which measured value is allocated to input channel 2 and displayed as Row 2.

Selection: (see 5.3.20.3)

### 5.3.20.5 Row 3

Selection of which measured value is allocated to input channel 3 and displayed as Row 3.

Selection: (see 5.3.20.3)

### 5.3.20.6 Units for FA and VA sensors

Selection of unit for measured value display and data logger

Selection:	<b>m/s</b>	=	flow velocity in meter / second
	<b>ft/min</b>	=	flow velocity in feet / minute
	<b>m<sup>3</sup>/h</b>	=	flow rate in m <sup>3</sup> / hour calculated from flow velocity and measuring section (FA: 5.3.2.2, VA: 5.3.8.1)
	<b>l/s</b>	=	flow rate in liter / second calculated from flow velocity and measuring section (FA: 5.3.2.2, VA: 5.3.8.1)
	<b>l/min</b>	=	flow rate in liter / minute calculated from flow velocity and measuring section (FA: 5.3.2.2, VA: 5.3.8.1)
	<b>cfm</b>	=	flow rate in cubic feet / minute calculated from flow velocity and measuring section (FA: 5.3.2.2, VA: 5.3.8.1)
	<b>kg/h</b>	=	mass flow rate in kg / hour calculated from flow velocity and measuring section (FA: 5.3.2.2, VA: 5.3.8.1), operating conditions (FA: 5.3.4, VA: 5.3.9), standard conditions (FA: 5.3.5, VA: 5.3.10) and the entered standard density.

**N-m<sup>3</sup>/h** = standard flow rate in standard-m<sup>3</sup> / hour calculated from flow velocity and measuring section (FA: 5.3.2.2, VA: 5.3.8.1), operating conditions (FA: 5.3.4, VA: 5.3.9) and standard conditions (FA: 5.3.5, VA: 5.3.10).

**N-l/min** = standard flow rate in standard-liter / minute calculated from flow velocity and measuring section (FA: 5.3.2.2, VA: 5.3.8.1), operating conditions (FA: 5.3.4, VA: 5.3.9) and standard conditions (FA: 5.3.5, VA: 5.3.10).

### 5.3.20.7 Units for TA sensors

Selection of unit for measured value display and data logger

Selection: **N-m/s** = standard flow velocity in meter / second

**N-ft/min** = standard flow velocity in feet / minute

**N-m<sup>3</sup>/h** = standard flow rate in m<sup>3</sup>/ hour calculated from flow velocity, measuring section (see 5.3.13.1) and standard conditions (5.3.14)

**N-l/s** = standard flow rate in liter / second calculated from flow velocity, measuring section (see 5.3.13.1) and standard conditions (5.3.14)

**N-l/min** = standard flow rate in liter / minute calculated from flow velocity, measuring section (see 5.3.13.1) and standard conditions (5.3.14)

**N-cfm** = standard flow rate in cubic feet / minute calculated from flow velocity, measuring section (see 5.3.13.1) and standard conditions (5.3.14)

**kg/h** = mass flow rate in kg / hour calculated from flow velocity, measuring section (see 5.3.13.1), standard conditions (5.3.14) and the entered standard density.

## Long-term measurement settings:

### 5.3.21 Long-term measurement

*Menu -> Settings -> Long-term measurement*

#### 5.3.21.1 Mode

Setting measuring mode for long-term measurement

Selection: **Start/Stop** = **Start/Stop mode** for long-term measurement  
**Start** = **Start mode** long-term measurement  
also enter:  
**interval/s** = duration seconds  
**Auto** = **automatic mode** for long-term measurement  
also enter:  
**interval/s** = duration in seconds  
**no. of values** = number of long-term measured values  
**Single measurements** = **single mode** with averaging via individually saved values

### Description of long-term measurement with selection of various measuring modes:

#### LM Start/Stop mode is set:

1. press **f2** LM-START to start long-term measurement. Displayed is the instantaneous value and the measurement period in seconds (e.g. S00010) continually in the status field top right.

2. press **f2** LM-STOP to stop long-term measurement, the display is frozen and the average value is displayed above the measurement period in seconds (e.g. S00030).
3. press **f2** LM-OK to exit display of average value, the instantaneous value is once again displayed and is ready for a new measurement. Start a new measurement as described under 1.

#### **LM Start mode is set:**

1. press **f2** LM-START to start long-term measurement. The instantaneous value is displayed and the duration of measurement in seconds (e.g. S00010) is displayed continually. The bar above the control key description shows the progress of the measurement period in relation to the set interval.
2. press **f2** LM-STOP before reaching the set interval and long-term measurement stops, the display is frozen and the average value is displayed above the measurement period in seconds (e.g. S00020). If LM-STOP is not activated, the measurement period runs up to the set interval, then long-term measurement is stopped, the display is frozen and the average value is displayed above the measurement period in seconds (e.g. S00030).
3. press **f2** LM-OK to exit display of average value, the instantaneous value is once again displayed and is ready for a new measurement. Start a new measurement as described under 1.

#### **LM Automatic mode is set:**

1. if **f2** LM-START is pressed, long-term measurement commences, in the 1<sup>st</sup> interval displaying the instantaneous value, in the status field top right the measurement period in seconds (e.g. S00010) continually and below this the number of measured values (R00001). The bar above the control key description shows the progress of the measurement period in relation to the set interval. After the 1<sup>st</sup> interval has elapsed the display is frozen and the next interval starts automatically, displaying the average of the previous interval during the set length, the measurement period in seconds continually in the status field and below it the number of values (R00002), ...
2. if **f2** LM-AUTO is pressed before the set number of long-term measurement transmissions is reached, then long-term measurement is aborted and awaits a new input as under 1. If LM-AUTO is not activated, the measurement period runs to the end of the set number of intervals, long-term measurement is then stopped, the display frozen and displays the last average value above the displayed measurement period in seconds in the status field top right, and below it the number of recorded values.
3. press **f2** LM-OK to exit display of average value, the instantaneous value is once again displayed and is ready for a new measurement. Start a new measurement as described under 1.



If the data logger is switched on (see 5.3.24.1), the displayed average is saved to the data logger with time stamp after each interval sequence, in the 3 modes described above.

#### **LM single measurement mode is set:**

1. each time **f2** LOG + is pressed the displayed instantaneous value is buffered as an individual value and the number of the buffered values (e.g. +00010) is displayed in the status field top right.
2. by pressing **f3** LOG – the last recorded individual value is deleted and in the status field top right the number of buffered values (e.g. +00010) is reduced by one. At the most the last 10 individual values may be discarded.

3. by pressing  **AVG** the average value of the buffered single measurements is calculated and shown on the frozen display and the number of single measurements used for averaging are displayed in the status field.

4. by pressing  **LOG-OK** display of the average value is exited, the instantaneous value is once again displayed and is ready for a new measurement. Start a new measurement as described under 1.



If the data logger is switched on (see 5.3.24.1), the average is saved to the data logger with time stamp by pressing  **AVG**.

## Device settings:

### 5.3.22 Device

*Menu -> Settings -> Device*

The parameter to be set here affects the flowtherm NT

- Selection:
- Date:** = sets the **actual date**
  - Time:** = sets the **actual time**  
When changing the batteries the date and time are buffered for several hours.
  - Supply:** = **battery:** 4 Alkali-Mangan Mignon (AA)  
**accumulator:** 4 NiMh Mignon (AA)  
this setting influences the battery charging level display
  - Light:** = display light **On** or **Off** after switching on the device
  - Language:** = selection of man-machine language **German, English, French** or **Japanese**

## Factory settings:

### 5.3.23 Factory settings

*Menu -> Settings -> Factory settings*

The flowtherm NT is reset to factory settings, all settings are lost if they have not been previously saved to a profile of their own (see 5.3.26).

The factory settings are preset as those found in the shipping documents. The values of customer or application-specific measuring tasks as defined in the documents are taken into account.

Before restoring the factory settings the following confirmation prompt appears:

**Restore factory setting?** Confirm with . Cancel with  or  MESS.



Before resetting to factory settings save the actual settings to a profile (see 5.3.26), otherwise they will be lost. Cancelling the factory settings does not affect the saved profile.

## Data logger:

### 5.3.24 Data logger

*Menu -> Data logger or  LOGGER*

The data logger is for saving measured values generated in various measuring modes of long-term or single measurement (see 5.3.21.1). The contents of the data logger can be viewed on the unit or downloaded, saved and subsequently processed via the USB port on a Windows PC with help of the optional HLOG II software.

The measured values, defined under (5.3.20) for rows 1...3 are saved to the data logger. Date and time are not logged separately, if these have been selected for measurement display.

Note: In this way the possible number of data records to be logged can be increased, as the length of the data record is thus reduced. This has no impact on the time stamp for the logged values.

### 5.3.24.1 On / Off

Selection: **Data logger:** = **On** or **Off**

Switch data logger on or off

With data logger on the data for long-term measurement

(see 5.3.21) is saved to the data logger

The data logger can also be switched on from the measured value

display with  **LOGGER** (via Selection: Settings -> Data logger)

or with  **LOGGER-OFF** switched off.

### 5.3.24.2 View

The contents of the data logger are shown on the display:

With  to the next data set

With  back to menu

With  or  **MESS** back to measured value display

### 5.3.24.3 Settings

**Designation:** = freely adjustable **measuring point designation** with max. 8 digits for all subsequently saved data logger values until entering a new measuring point designation.

### 5.3.24.4 Delete

Delete the contents of the data logger:

Before deleting a prompt appears:

**Delete data logger?** Confirm with . Cancel with  or  **MESS**.

All the values saved to the data logger are deleted accordingly.



Before deleting, the data logger contents should be downloaded and saved via the USB port to a Windows PC with the help of the optional HLOG II software, otherwise they will be lost.

## Device status:

### 5.3.25 Device status

*Menu -> Status*

Display of status:

**Hardware:** = **hardware version**

**Software:** = **software version**

**S. No.:** = **serial no.**

**Memory/%:** = display of **free space for data logger** in %

**Battery/%:** = display of **battery capacity** in %

"0" is displayed when supply is via the USB connection.

When the battery symbol appears for the first time in the status field top right there is approx. 10 % battery capacity available.

**Profile:** = last loaded profile (see 5.3.26)



When using rechargeable batteries, "rechargeable" must be selected in the settings (5.3.22) otherwise the battery capacity display will be incorrect!

## Device profiles:

### 5.3.26 Device profiles

*Menu -> Profiles*

The entire parameter inputs can be saved in the profiles under a freely definable name with up to 8 characters and can subsequently be reloaded.

For example, all parameter inputs for a specific sensor can be saved to a profile or also to an appointed measuring point.

Up to 100 different profiles can be saved. Available profile storage locations are marked with an \* after the profile name. Profiles cannot be deleted but may be overwritten.



Returning to the factory settings (5.3.23) has no impact on the saved profiles.

Selection:     **Load:**             = **loading a saved profile** by selecting from the list

**Save:**             = **saving the active parameter settings** to a profile by selecting from the list in an available profile storage field and input of a new name or in an already occupied profile storage location by overwriting and changing or retaining the name

## Keys:

### 5.3.27 Key F3 - LM-Start

 Funktion key for operating long-term measurement (see 5.3.21)

### 5.3.28 Key 4 Switch off / OFF (reset)

 Funktion key for switching off the device; active in all menus except during long-term measurement. If the device no longer reacts to keypad entry, hold this key down for longer than 10 seconds to switch off and reset.

## 6 Troubleshooting

<b>Fault</b>	<b>Cause</b>	<b>Troubleshooting</b>
<b>Device cannot be switched on</b>	Dead batteries	Insert new / re-charged batteries
	Faulty electronics	Return to Höntzsch
<b>No measured value display or analog output = 0V no value</b>	Sensor contaminated	Clean according to instructions
	Profile factor set at 0.000	Set profile factor to the corresponding value of nominal diameter and sensor type
	Unit setting (5.3.20.1) does not correspond to the connected flow sensor	Adjust the setting (5.3.20.1) to the connected sensor or connect compatible sensor
<b>Analog output = 0V no value</b>	Output setting does not match the port or source (5.3.18)	Amend output setting port or source (5.3.18)
<b>Measured value too low</b>	Sensor type or KKZ set incorrectly	Compare and correct settings according to details in the Technical Data Sheet
	Sensor contaminated	Clean according to instructions
	Profile factor set too low	Set profile factor to the corresponding value of nominal diameter and sensor type
	Input/output section too short	Change sensor position; improve flow conditions with a flow straightener
	Rotational flow	Reposition sensor in flow direction; use flow straightener
	Vortex VA sensors: reduced acoustic coupling in the sensor elements as a result of vibration or impact	Return sensor to Höntzsch for checking
<b>Measured value too high</b>	Sensor type or KKZ set incorrectly	Compare and correct settings according to details in the Technical Data Sheet
	Incorrect scaling of analog output	Check settings and amend if necessary
	Profile factor set too high	Set profile factor to the corresponding value of nominal diameter and sensor type
	EMC problem	See reference to electromagnetic compatibility (EMC) in the sensor documents

## 7 Replacement Parts

- upper housing with keypad
- lower housing
- battery compartment cover
- seal for upper housing
- connector socket cap
- USB connection cover
- 12-pin connector plug



## 8 Installation

The current European Specifications for Assembly, the recognised standards of good practice and this Instruction Manual apply.



## 9 Maintenance

Any maintenance and repair work is to be carried out solely by Höntzsch GmbH.